



P.O. BOX 385    331 Platt Street    Lansing, IA 52151  
PH: 800-331-8200    FAX: 563-538-4392  
[www.ToughTekMetals.com](http://www.ToughTekMetals.com)

---

## Storm/Screen Door Installation Instructions

### Doors come Pre-Hung in Z-Bar frame

For easy Installation

- Step 1            Remove two shipping screws from latch side of the door
- Step 2:            Cut the bottom of the z-bar frame to fit the opening, place door in opening.
- Step 3:            Making sure Z-Bar is tight against jamb on hinge side, install No. 8 x 1" round head Philips screws through holes in face of Z-Bar, hinge Side. **(Do not over tighten screws. If mounting into a steel frame, pre-drill screw holes.)**
- Step 4:            With door square in opening, install one No. 8 x 1" round head Philips drive screw in header.
- Step 5:            With the door in the closed position, square header and latch side leaving no less than 1/8" clearance between door and header; and no less than 1/8" evenly spaced from top to bottom between door and the latch side Z-Bar.
- Step 6:            Install No. 8 x 1" round head, Philips screws in remaining Z-bar face holes on latch side and header.
- Step 7:            Install No. 8 x 1.25" flat head Philips screw through center holes in the hinges into the door casing. This screw is provided in the std. screw pack in the door kit box. Pre-drill this hole.
- Step 9:            Attach handle hardware according to instructions in hardware kit. Attach closer and wind chain per hardware kit instructions.
- (WE RECOMMEND THAT CLOSER IS ATTACHED ON UPPER RAIL IN THE CENTER OF THE DOOR)
- Step 10:            Install box sweep on the bottom of the door to the inside with No. 8 x 1/2" sheet metal screws. Adjust for proper fit.

## **Installation Tools**

- 1. Tape Measure**
- 2. Pencil to mark holes**
- 3. Philips screw driver**
- 4. Electric/cordless drill with 1/8 inch drill bit**
- 5. Hacksaw**